



b57util

## Utilities Program Users Guide

**Version 1.6 • Date 01/31/01**

**Prepared by: Tak Tomita**

Copyright © 2000, 2001 Broadcom Corporation  
All Rights Reserved

No part of this document may be reproduced, in any form or by any means, without permission in writing from Broadcom Corporation.

Broadcom Corporation reserves the right to make changes to the products or information contained in this document without notice. No liability is assumed as a result of their use or application. No rights under any patent accompany the sale of any such products or information.

Epigram, InsideLine, and iLine10 are trademarks of Broadcom Corporation.

Broadcom Corporation  
16125 Alton Parkway  
Irvine, CA 92619-7013  
[www.broadcom.com](http://www.broadcom.com)

<b>1. INTRODUCTION .....</b>	<b>1</b>
<b>2. PREREQUISITES .....</b>	<b>2</b>
<b>3. FUNCTIONS LIST .....</b>	<b>3</b>
<b>4. FUNCTIONS DESCRIPTION .....</b>	<b>4</b>
4.1 wole	4
4.2 wold	4
4.3 pxee	5
4.4 pxd	5
4.5 pxes	5
4.6 upgf	6
4.7 ver	6
4.8 help	6
4.9 exit	7

## 1. Introduction

This document provides the information on how to use the b57util utilities DOS program on Broadcom Gigabit Ethernet adapter, in particular BCM5700 and its related components.

All commands can be entered from DOS prompt or CLI, the Command Line Interface, prompt. When program is run without parameter, the CLI mode is entered. Otherwise, the parameter will be used as command to be executed and exit the program after.

In CLI, assuming there are three devices in the system, all devices information always displayed before each prompt as the following example:

```
Dev Fmw Bus/Dev Perm.MACAddr SVID SSID Curr.MACAddr SVID SSID WOL PXE PXE Spd
=== === =====
0 1.2 03:09:0 00101801026C 14E4 1644 00101801026C 14E4 1644 no yes auto
1 1.0 03:0A:0 001018010278 14E4 1644 001018010278 14E4 1644 no no 100full
2 1.3 05:05:0 001018010212 14E4 1644 001018010212 14E4 1644 yes yes auto
```

```
b57util>wole all
Enabling wol for device 0
Enabling wol for device 1
Enabling wol for device 2
```

```
Dev Fmw Bus/Dev Perm.MACAddr SVID SSID Curr.MACAddr SVID SSID WOL PXE PXE Spd
=== === =====
0 1.2 03:09:0 00101801026C 14E4 1644 00101801026C 14E4 1644 yes yes auto
1 1.0 03:0A:0 001018010278 14E4 1644 001018010278 14E4 1644 yes no 100full
2 1.3 05:05:0 001018010212 14E4 1644 001018010212 14E4 1644 yes yes auto
```

```
b57util>
```

## 2. Prerequisites

**OS:** Dos 6.22

**Software:** b57util.exe.

### 3. Functions List

**Functions:**

Enable WOL  
Disable WOL  
Enable PXE  
Disable PXE  
Change PXE speed  
Upgrade EEPROM  
Software version  
Software Help  
Exit program

**cmd:**

wole  
wold  
pxee  
pxed  
pxes  
upgf  
ver  
help  
exit

## 4. Functions Description

### 4.1 wole

**cmd:** wole

**Description:**Enable WOL.

**Syntax:** [-]wole devnum

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The syntax for devnum is as followed:

<d [,d]... | all>

Where d is the device number 0 to number of devices – 1. For example, if you have three devices in the system, the valid device number is 0, 1, or 2.

**Example:**

*From DOS prompt:*

```
C:\>b57util wole 0           ; Enable WOL for device 0
C:\>b57util -wole all        ; Enable WOL for all devices found in the system
```

*From CLI prompt:*

```
b57util>wole 0,2             ; Enable WOL for device 0 and device 2
```

Please note there is no spaces allowed in the device list. Furthermore, the 'all' parameter must be in lower case.

The '-' before command is optional to support compatibility with b57man.

### 4.2 wold

**cmd:** wold

**Description:**Disable WOL.

**Syntax:** [-]wold devnum

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The devnum parameter is same as wole command. Please see wole command for the examples.

### 4.3 pxe

**cmd:** pxe

**Description:** Enable PXE.

**Syntax:** [-]pxe devnum

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The devnum parameter is same as wole command. Please see wole command for the examples.

### 4.4 pxd

**cmd:** pxd

**Description:** Disable PXE.

**Syntax:** [-]pxd devnum

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The devnum parameter is same as wole command. Please see wole command for the examples.

### 4.5 pxe

**cmd:** pxe

**Description:** Change PXE speed

**Syntax:** [-]pxe devnum <auto | 10half | 10full | 100half | 100full>

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The devnum parameter is same as wole command. The speed must be entered in lower case and exact spelling as stated in the Syntax.

**Example:**

Changes all device to speed auto for PXE.

```
C:\>b57util pxe all auto
```



## 4.6 upgf

**cmd:** upgf

**Description:** Upgrade the EEPROM content

**Syntax:** [-]upgf devnum <boot | base | pxe | undi> [path]

devnum : Device number. It can be one or more devices in the list. Use 'all' for all devices.

The devnum parameter is same as wole command. Please see wole command for the examples.

There are four kinds of images can be programmed in to EEPROM: eeprom.bin, b57base.bin, b57pxe.bin, and b57undi.bin.

When 'boot' option is entered, the firmware boot code "eeprom.bin" is programmed into eeprom. When one of 'base', 'pxe', and 'undi' parameter is entered, the b57xxx.bin image is programmed into PXE area.

The optional [path] parameter is used to specify where the file is if it is not in the same directory as b57util.exe.

## 4.7 ver

**cmd:** ver

**Description:** Display software version.

**Syntax:** ver

**Example:**

```
C:\>b57util -ver
b57util.exe V1.6
Copyright (c) 2000, 2001 Broadcom Corporation, all rights reserved
```

## 4.8 help

**cmd:** help

**Description:** Display help

**Syntax:** help

**Example:**

```
C:\>b57util -help
b57util.exe V1.6
Copyright (c) 2000, 2001 Broadcom Corporation, all rights reserved

wole                WOL Enable
```

wold	WOL Disable
pxee	PXE Enable
pxed	PXE Disable
pxes	PXE speed
upgr	Upgrade eeprom content
help	Display Help
ver	Display software version
exit	Exit software

## 4.9 exit

**cmd:** exit

**Description:**Exit program.

**Syntax:** exit from CLI mode.

**Example:**

b57util> exit