

Panasonic


Stereo Radio Cassette Player Operating Instructions

Model No. **RQ-CR18V**



Before connecting, operating or adjusting this product, please read these instructions completely. Please keep this manual for future reference.

P




Supplied Accessories

- ① Stereo headphones RFEV705P-KY
- ② Belt clip RKQT0008-A

To order accessories contact 1-800-332-5368 or web site (<http://www.panasonic.com>).

• Use numbers indicated when asking for replacement parts.

Attaching the belt clip



CAUTION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Panasonic Consumer Electronics Company,
Division of Matsushita Electric Corporation of America
One Panasonic Way Secaucus, New Jersey 07094
<http://www.panasonic.com>

Panasonic Sales Company, Division of
Matsushita Electric of Puerto Rico, Inc. ("PSC")
Ave. 65 de Infantería, Km. 9.5 San Gabriel Industrial
Park, Carolina, Puerto Rico 00985
©2001 Matsushita Electric Industrial Co., Ltd.
Printed in China

RQTT0473-P
F1101MA0

1

INSTALL BATTERIES.

Press in and down towards the ⊖ end.

Two R6/LR6, AA, UM-3 batteries (not included)

2

CONNECT THE HEADPHONES.

Plug in firmly.

Plug type: 3.5mm (1/8 in.) stereo

3

BATTERY CONDITION

CHANGING THE BASS

XBS OFF ● ON

RADIO

TAPE

① INSERT A CASSETTE.

Forward side*
*[DIR] switched to FWD

② PRESS [◀▶].

ADJUST THE VOLUME.

VOL

SELECT THE STATION.

③ SELECT THE STATION.

① RELEASE THE HOLD STATE.

② SELECT THE BAND.

Basic Operation

TAPE PLAYBACK

| Function | Operation |
|---------------------------|--|
| To stop | During playback, press [■]. |
| To fast forward or rewind | [DIR] switched to FWD: In the stop mode, press [▶▶] (fast forward) or [◀◀] (rewind). [DIR] switched to REV: In the stop mode, press [◀◀] (fast forward) or [▶▶] (rewind). |
| Reverse tape direction | In the stop mode or during playback, set [DIR] to REV or FWD. |

You can use normal type tapes only. This unit will not be able to do full justice to characteristics of high and metal position tapes even if they are played back.

RADIO RECEPTION

| Function | Operation |
|----------|---|
| To stop | During reception, press [RADIO ON/OFF]. |

NOTE:
Press [■] to stop the tape before operating the radio. While playing a tape, the radio will not turn on even if you press [RADIO ON/OFF].

BEFORE CALLING



Before requesting service, make the below checks. If you are in doubt about some of the check points, or if the remedies indicated in the chart do not solve the problem, contact the **Panasonic Customer Call Center at 1-800-211-7262, or e-mail consumerproducts@panasonic.com, or web site (<http://www.panasonic.com>).**

| Problem | Checkpoint |
|--|---|
| No tape operations in spite of radio operations. | Are the batteries worn? |
| No radio operations. | • Is the unit in the hold state? • Is a tape playing? |
| No operations. | Have the batteries been installed with their polarities (⊕, ⊖) reversed? |
| • No sounds. • A gritty noise is heard. | • Is the headphone plug firmly connected to the [🎧] jack? • Is the plug dirty? |
| Cannot hear music - too noisy. | Separate the unit from mobile phones. |

