
Panasonic

AC Adaptor


AJ-B95p

Operating Instructions





CAUTION





CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER SERVICEABLE PARTS INSIDE.
REFER TO SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (service) instructions in the literature accompanying the appliance.

FCC Note:

This device complies with Part 15 of the FCC Rules. To assure continued compliance follow the attached installation instructions and do not make any unauthorized modifications.

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction harmful interference manual. may cause to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

indicates safety information.

CAUTION:

Do not install or place this unit in a bookcase, builtin cabinet or any other confined space in order to maintain adequate ventilation. Ensure that curtains and any other materials do not obstruct the ventilation to prevent risk of electric shock or fire hazard due to overheating.

WARNING:

TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION:

TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD AND ANNOYING INTERFERENCE, USE THE RECOMMENDED ACCESSORIES ONLY.

Note:

The rating plate (serial number plate) is on the bottom of the unit.

■ If the unit is not going to be used for length of time, turn the power OFF and disconnect the power plug from the AC outlet.

Contents

Features	4
Specifications	4
Parts and their functions	5
Connections	6

Features

This unit is an AC adaptor with XLR 4-pin specifications.

It is used to supply power to a laptop editor, video camera or other product from AC power supply.

Specifications

Rated input voltage:

AC 120 V, 50 - 60 Hz, 250 W

Rated output voltage:

DC OUT (XLR 4-pin), DC 12 V, 13 A

Weight:

Approx. 6.38 lb (2.9 kg)

Dimensions (W \times H \times D):

 $3-11/16" \times 5-9/16" \times 13" (93 \times 140.5 \times 329 \text{ mm})$

(excluding cord hooks)

Ambient operating temperature:

32°F to 104°F (0°C to 40°C)

Ambient operating humidity:

Less than 80% (RH)

Accessories supplied:

AC power cord ×1 DC cable ×1

Parts and their functions


POWER switch

This is the power switch.

2 POWER lamp

6 FAN WARNING

When the fan stops, this lamp lights to indicate a malfunction in the product. When this symptom occurs, switch off the power



4 DC OUT connector (XLR)

The power to the laptop editor or video camera is supplied through this connector.

Use the accessory DC cable to connect it to the DC IN connector on the product to be connected.

Pin signal:


- 1. GND
- 2. N.C
- 3. N.C
- 4. +12V

Parts and their functions

FAN

AC IN socket

This is the unit's power socket (3-pin). Use the accessory power cord to the AC power outlet.



Connections

Before proceeding with the connections, turn off the power to all the products.

- 1. After having performed the connections, connect the power cord to the power outlet.
- 2. Set the unit's POWER switch to ON.
- 3. Turn on the power to the connected products.



Panasonic

PANASONIC BROADCAST & DIGITAL SYSTEMS COMPANY DIVISION OF MATSUSHITA ELECTRIC CORPORATION OF AMERICA

Executive Office:

3330 Cahuenga Blvd W., Los Angeles, CA 90068 (323) 436-3500

EASTERN ZONE:

One Panasonic Way 4E-7, Secaucus, NJ 07094 (201) 348-7621 Mid-Atlantic/New England:

One Panasonic Way 4E-7, Secaucus, NJ 07094 (201) 348-7621

1225 Northbrook Parkway, Ste 1-160, Suwanee, GA 30024 (770) 338-6835

Central Region:

Southeast Region:

1707 N Randall Road E1-C-1, Elgin, IL 60123 (847) 468-5200

WESTERN ZONE:

3330 Cahuenga Blvd W., Los Angeles, CA 90068 (323) 436-3500

Dallas Region:

6226 Abington Way, Houston, TX 77008 (713) 802-2726

No. CA/Northwest Region:

5870 Stoneridge, #3, Pleasanton, CA 94588 (925) 416-5108

Government Marketing Department:

52 West Gude Drive, Rockville, MD 20850 (301) 738-3840

PARTS INFORMATION & ORDERING:

9:00 a.m. - 5:00 p.m. (EST) (800) 334-4881/24 Hr. Fax (800) 334-4880

TECHNICAL SUPPORT:

Emergency 24 Hour Parts & Service (800) 222-0741

TRAINING INFORMATION:

Digital System Products - (201) 392-6852

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3 (905) 624-5010

Panasonic de Mexico S.A. de C.V.

Av angel Urraza Num. 1209 Col. de Valle 03100 Mexico, D.F. (52) 1 951 2127

