














Basic Operation

Make a call	Phone number + 
End a call	
Answer a call	
Redial the last call	 twice or press and hold
Switch to Vibrate mode	(in Standby mode) Hold #
Switch to 1-Beep mode	(in Standby mode) Hold 0
Lock the keypad	(in Standby mode) Hold *
Unlock the keypad	C + *
Enter Lock Mode	Menu 7-3-1 + Select Lock type + Select

Internal Phone Book

Save a number	Enter number + Save + Select + Enter name + Next +  /  (Category) + Select +  /  (Entry option) +  /  to change the settings or Edit enter information + Save
Speed dial	<ul style="list-style-type: none"> For the entry numbers of one digit, press and hold the corresponding digit key. For the other entry numbers, press the first digit key(s) briefly, and hold down the last digit key.
Phone Book Search	Press the Find soft key +  /  + Select or 

Main Menu (To access, press the Menu soft key.)

1: Phone Book	<ol style="list-style-type: none">1: Find2: Add Entry3: Groups4: Memory Status	6: Organiser	<ol style="list-style-type: none">1: Scheduler2: Task List3: Memo Pad4: Alarm5: Calculator6: World Time7: Count Down
2: Messages	<ol style="list-style-type: none">1: Write2: Inbox3: Outbox4: Drafts5: Templates6: Erase Messages7: Settings8: Voice Mail9: SMS Groups	7: Settings	<ol style="list-style-type: none">1: Call<ol style="list-style-type: none">1: Answer Mode2: Auto Redial3: Call Forward4: Call Waiting2: Phone/System<ol style="list-style-type: none">1: Key Guard2: Set Time3: Set NAM4: Version3: Security<ol style="list-style-type: none">1: Lock Mode2: Change Code3: Emergency Numbers4: Voice Privacy5: Clear Phone Book6: Reset Phone7: Clear SMS Groups
3: Call History	<ol style="list-style-type: none">1: Missed2: Received3: Dialed4: Erase History5: Call Duration		
4: Sound	<ol style="list-style-type: none">1: Ring Tones2: Ringer Volume3: Alerts4: Key Tone5: Power On/Off Melody		
5: Display	<ol style="list-style-type: none">1: Language2: Service Area3: Wallpaper4: Banner5: Backlight6: LCD Contrast	8: Games	<ol style="list-style-type: none">1: Child Monk Adventure2: Black Planet3: Hello Monkey4: Bowling5: Othello6: Settings